SAMSUNG

OWNER'S INSTRUCTIONS
MANUAL DE INSTRUCCIONES
MANUEL D'UTILISATION

ENGLISH

ESPAÑOL

FRANÇAIS

Indoor unit	Outdoor unit
AST12SBGB	UST12SBGB
AST18S0GB	UST18S0GB
AST18S0GE	UST18S0GE
AST24S6GB	UST24S6GB
AST24S6GE	UST24S6GE

Split-type Room Air Conditioner (Cool)
Aire acondicionado doméstico sistema Split (Refrigeración)
Climatiseur de type Séparé (Refroidissement)



ⒺⓈⒻⒶ DB98-09949A(3)

Safety Precautions

⚠ WARNING

- If the power supply cord of this air conditioner is damaged, it must be replaced by the manufacturer or its authorized service personnel only in order to avoid a safety hazard.

⚠ DANGER

- Do not attempt to install the air conditioner by yourself.
- This unit contains no user-serviceable parts. Always consult authorized service personnel for repairs.
- When moving, consult authorized service personnel for disconnection and installation of the unit.
- Do not become over-exposed to cold air by staying in the direct path of the air flow of the air conditioner for extended periods of time.
- Do not insert fingers or objects into the outlet port or intake grilles.
- Do not start and stop air conditioner operation by disconnecting the power supply cord and so on.
- Take care not damage the power supply cord.
- In the event of a malfunction(burning smell, etc.), immediately stop operation, turn off the electrical breaker, and consult authorized service personnel.

⚠ CAUTION

- Provide occasional ventilation during use.
- Do not direct air flow at fireplaces or heating apparatus.
- Do not climb on, or place objects on, the air conditioner.
- Do not hang objects from the indoor unit.
- Do not set flower vases or water containers on top of air conditioner.
- Do not expose the air conditioner directly to water.
- Do not touch the power supply plug with wet hands.
- Do not turn off the air conditioner with pulling power cord.
- Turn off power source when not using the unit for extended periods.
- Do not place animals or plants in the direct path of the air flow.
- Do not drink the water drained from the air conditioner.
- Do not use in applications involving the storage of foods, plants or animals, precision equipment, of art works.
- Do not block or cover the intake grille and outlet port in use.
- Do not use inflammable gases near the air conditioner.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent. (For Europe)
- Before throwing out the device, it is necessary to pull back the battery cells and get rid of them safely.

Contents

◆ ***PREPARING YOUR AIR CONDITIONER***
- ■ Safety Precautions 2
- ■ View of the Unit 4
- ■ Remote Control-Buttons and Display 6
- ■ Getting Started 7
- ■ Inserting the Remote Control Batteries 8

◆ ***OPERATING YOUR AIR CONDITIONER***
- ■ Selecting the Automatic Operating Mode 9
- ■ Cooling Your Room 10
- ■ Changing the Room Temperature Quickly 11
- ■ Removing Excess Humidity 12
- ■ Airing Your Room 13
- ■ Selecting Energy Saving Mode 14
- ■ Adjusting the Air Flow Direction Vertically 15
- ■ Adjusting the Air Flow Direction Horizontally 15

◆ ***PROGRAMMING YOUR AIR CONDITIONER***
- ■ Setting the On Timer 16
- ■ Setting the Off Timer 17
- ■ Setting the Sleep Timer 18

◆ ***RECOMMENDATIONS FOR USE***
- ■ Operating Recommendations 19
- ■ Temperature and Humidity Ranges 19
- ■ Operating Your Air Conditioner Without the Remote Control 20
- ■ Solving Common Problems 21
- ■ Cleaning Your Air Conditioner 22
- ■ Cleaning Deodorizing and Bio-Green filters (option) 22

◆ ***TECHNICAL SPECIFICATIONS***

Preview Limit Reached! To view more of this manual, please visit:
http://freemanualdownload.com/Samsung-UST18S0GE-free-manual-download